
VR1
VR2
VR7A
VR3
VR7B
VR4
VR8A
VR5
VR8B
VR6
+15V DC
OFF/ON
NTSC/PAL
VIDEO IN
VIDEO OUT
RATE A
RANDOM A
DELAY A
DELAY B
FX ON/OFF
RATE B
RANDOM B
WIPE 1
WIPE 2
FDBK 1
FDBK 2
DISCRET11
+15V DC
0.25A
ON/OFF
PAL/NTSC
VIDEO IN
VIDEO OUT